

# 46—010 Differentiating characteristics of steering gears

## A. Power steering 765 (LS 90, LS 68)

Part No.	Installed in model	Steering gear	Reaction piston dia.	Code number	Pitch Ball circulation	Remarks
107 460 13 01 LL <sup>1</sup> ) 107 460 14 01 RL <sup>2</sup> )	107. 1st version	765.700	11	—	10.5	—
114 460 17 01 LL <sup>1</sup> ) 114 460 18 01 RL <sup>2</sup> )	107 2nd version 114, 115 1st version	765.700	10	—	10.5	—
114 460 08 01 LL <sup>1</sup> ) 114 460 09 01 RL <sup>2</sup> )	107 3rd version 114, 115 2nd version 116.02, 116.032/033 1st version	765.701	10	—	10.5	—
114 460 21 01 LL <sup>1</sup> ) 114 460 22 02 RL <sup>2</sup> )	107 4th version 114, 115 3rd version	765.701	11	1	10.5	—
107 460 17 01 LL <sup>1</sup> ) 107 460 18 01 RL <sup>2</sup> )	107 5th version 114, 115 4th version 123 1st version	765.701	11.5	1	10.5	—
107 460 19 00 LL <sup>1</sup> )	107 6th version	765.701	11.5	1	10.5	Identification "S" on steering case = additional stop
116 460 10 01 LL <sup>1</sup> ) 116 460 11 01 RL <sup>2</sup> )	116.02 116.032/033 2nd version	765.702	9	9	10.5	—
116 460 12 01 LL <sup>1</sup> ) 116 460 13 01 RL <sup>2</sup> )	116.036	765.703	8	8	10.5	—
123 460 47 01 LL <sup>1</sup> ) 123 460 48 01 RL <sup>2</sup> )	123 2nd version	765.704	11.5	1	10.5	Steering locks in steering case, identification "A"
123 460 58 01 LL <sup>1</sup> ) 123 460 59 01 RL <sup>2</sup> )	123 3rd version	765.704	11.5	1	9	

Part No.	Installed in model	Steering gear	Reaction piston dia.	Code number	Pitch Ball circulation	Remarks
126 460 04 01 LL <sup>1)</sup> 126 460 05 01 RL <sup>2)</sup>	126.02 126.03 1st version	765.706	13	—	10.5	Identification "D" (degressive reaction)
126 460 14 01 LL <sup>1)</sup> 126 460 15 01 RL <sup>2)</sup>	126.04 1st version 126.02 126.03 2nd version	765.706	13	—	10	Identification "D" and automatic compensation for play
201 460 57 01 LL <sup>1)</sup> 201 460 58 01 RL <sup>2)</sup>	201.02 1st version	765.900	11.5	—	10	Automatic com- pensation for play. Grey iron housing, with dowel sleeve
201 460 43 01 LL <sup>1)</sup> 201 460 49 01 RL <sup>2)</sup>	201.02 2nd version 201.1 1st version	765.900	11.5	—	10	Automatic com- pensation for play. Light alloy housing, with dowel sleeve
201 460 66 01 LL <sup>1)</sup> 201 460 67 01 RL <sup>2)</sup>	201.02 3rd version 201.1 2nd version	765.900	11.5	—	10	Automatic com- pensation for play. Light alloy housing, without dowel sleeve
201 460 60 01 LL <sup>1)</sup>	201.03	765.902	11.5	—	11	Automatic com- pensation for play. Light alloy housing, without dowel sleeve

<sup>1)</sup> LL = lefthand steering

<sup>2)</sup> RL = righthand steering

## B. Mechanical steering 760 (L 1 Z, L 075 Z)

Part No.	Installed in model	Steering gear	Pitch Ball circulation	Remarks
115 460 19 01 LL <sup>1)</sup> 115 460 20 01 RL <sup>2)</sup>	114, 115 1st version	760.100	9	Pertinent pitman arm 115 463 07 01 LL <sup>1)</sup> , 115 463 08 01 RL <sup>2)</sup>
115 460 21 01 LL <sup>1)</sup> 115 460 22 01 RL <sup>2)</sup>	114, 115 2nd version	760.100	10	Pertinent pitman arm 115 463 12 01 LL <sup>1)</sup> , 115 463 13 01 RL <sup>2)</sup>
123 460 38 01 LL <sup>1)</sup> 123 460 39 01 RL <sup>2)</sup>	123 1st version	760.100	9	Pitman shaft dia. 30 mm
123 460 62 01 LL <sup>1)</sup> 123 460 63 01 RL <sup>2)</sup>	123 2nd version	760.100	9	Pitman shaft dia. 32 mm
201 460 52 01 LL <sup>1)</sup> 201 460 55 01 RL <sup>2)</sup>	201 1st version	760.700	9	With dowel sleeve
201 460 68 01 LL <sup>1)</sup> 201 460 69 01 RL <sup>2)</sup>	201 2nd version	760.700	9	Without dowel sleeve

<sup>1)</sup> LL = lefthand steering

<sup>2)</sup> RL = righthand steering